

XRAY BOB

COMMENTS

The diagram illustrates the front and rear suspension setups. For the front suspension, the camber is set to 3 degrees, shock preload is in mm, the control arm is in stock position, and the ride height is 22 mm. For the rear suspension, the camber is set to 3 degrees, shock preload is in mm, the control arm is in stock position, and the ride height is 25 mm. A #107717 GAUGE is used to measure the ride height.